

Earthborn Furniture Glaze

Earthborn Furniture Glaze is a clear, water-based glaze designed to protect painted furniture. Glazed surfaces will remain durable with a soft sheen finish; repelling water, dust and grease.

1. Coverage

Up to 9m² per litre.

2. Colours

Clear

3. Pack Size

400ml

4. Thinner

N/A

5. Uses

Earthborn Furniture Glaze can be used over Earthborn Eco Chic Claypaint for furniture and offers protection to various decorative effects, including Earthborn Crackle.

6. Ingredients

Water, acrylic binder, fumed silica, coalescent, wax, defoaming agent, amine, synthetic preservative (methylisothiazolinone).

7. Properties

Clear, low sheen and durable finish.

8. Preparation

The surface should be clean, dry and free from dust and grease. Non-absorbent or gloss surfaces should be lightly sanded first.

9. Instructions for Use

Stir before use.

10. Application

Apply over the painted surface with a brush, working in smooth strokes. When dry, apply a further coat for optimum protection.

Broken colour work: Make a solution of Earthborn Pigment by adding approximately 100ml of water to the desired quantity of Pigment and leave to soak for up to 30 minutes.

Mix the resultant solution with more water if necessary and then add Earthborn Furniture Glaze (recommended ratio 1-part Furniture Glaze to 4 part solution). Apply to surface using sponge, brush or other desired technique.

Colour wash: Mix Earthborn Furniture Glaze and Pigment using the proportions and method described for Broken Colour Work. Spread the resultant colour wash onto a dry base coat of

emulsion with a brush or a natural sponge and blend, if desired, using a dry paintbrush. Work diagonally starting in a top corner. For best results apply more than one colour wash, varying the colour as desired.

11. Colouring – Depends on if products needs it)

N/A

12. Drying Time

Touch dry in 1-2 hours. Allow 6-12 hours before overpainting. Maximum durability will be achieved after 10 days.

13. Tools

Brush.

14. Cleaning

Clean tools with water.

15. Maintenance

Painted surfaces can be cleaned with a soft cloth or sponge and water, do not use abrasive or micro-fibre cloths. Avoid excessive rubbing as this may leave a visible mark when dry. The use of harsh detergents to remove stains is not recommended.

16. Storage & Disposal

Keep containers sealed and store in a dry, cool, frost-free place.

Any leftover paint should not be emptied into drains or watercourses but allowed to dry and reference made to local authority disposal guidelines.

17. Safety

Please refer to Materials Safety Data Sheet.

18. Water Vapour Permeability

N/A

19. Moisture Vapour Transmission

N/A

20. VOC Content

N/A

21. Safety of Toy Standards (EN71-3:2019)

NB: The user is recommended to test the product on the intended surface to ensure its suitability

Earthborn Furniture Glaze can deepen some paint colours by a shade or two. We recommend you test it in a discreet area of the intended surface before application.

